

QUIK STICK" SPRAY ADHESIVE



Directions:

IMPORTANT: PRODUCT MAY AFFECT SOME PAINTS AND PLASTICS, PROTECT ADJACENT SURFACES FROM OVERSPRAY.

- 1. Shake can well.
- 2. Make certain both surfaces to be bonded are clean and dry.
- 3. Holding can about 8-12 inches away, spray QUIK STICK™ on both surfaces. Use short even strokes.
- 4. Allow a few minutes for product to become tacky before sticking surfaces together. If necessary, materials can be repositioned up to 15 minutes later.
- 5. When job is complete, clean valve by inverting can and spraying until only pressure escapes.
- 6. Any overspray or excess adhesive can be removed with either mineral spirits or alcohol.

NOTE: When a temporary bond is desired, or when working on porous materials, spray only one side and attach.

(50°C). Do not puncture, incinerate or burn can.

wellworthproducts.com.

First Aid Measures:

Storage:

 EYE CONTACT: Wash eyes with fresh water. If irritation continues, get medical attention.

For complete product specifications, review the product SDS at

SKIN CONTACT: Wash skin with soap and fresh water. If irritation continues. get medical attention.

Keep away from heat, sparks or open flame. Store at temperatures below 120°F

- INHALATION: Remove to fresh air. Give oxygen. Get medical attention.
- INGESTION: Do not induce vomiting-gastric lavage. Get medical attention.

ChemTrec (USA) 800-424-9300

Product Number and Packaging: #3004 - Net wt. 13.25 oz. Aer......12 per case