



# **STOP WELL**™ Cooling System Sealer

## **Directions:**

DO NOT REMOVE RADIATOR CAP WHILE ENGINE IS HOT.

- 1. With the engine off and cool, remove radiator cap.
- 2. Shake well.
- 3. Make certain radiator is almost full. Start engine and bring engine up to operating temperature.
- 4. Pour in entire contents and allow to circulate until leak stops.

#### **Uses:**

- Seals Leaks
- Compatible With All Types of Coolant Including Extended Life
- Prevents Leaks

## Packaging:

For complete product specifications, review the product MSDS/SDS at wellworthproducts.com.

### Storage:

Do not store in temperatures above 120°F (50°C). Keep away from heat, sparks or open flame.

#### First Aid Measures:

- EYE CONTACT: Flush with large amounts of water for 15 minutes.
- SKIN CONTACT: Flush with large amounts of water for 15 minutes.
- INHALATION: Remove victim to fresh air and get medical attention.
- INGESTION: Drink water to dilute. Get medical attention.

ChemTrec (USA) 800-424-9300

#### **HMIS HAZARD RATING**

0-Least A-Goggles
1-Slight B-Goggles, Gloves
2-Moderate C-Goggles, Gloves
3-High Protective Wear
4-Extreme

NOTICE TO PURCHASER: Well\*Worth Products, Inc. provides no warranty of any kind with respect to the product, whether express or implied including without limitation, the implied warranty of merchantability or fitness for any intended use or purpose; shall not be liable under any circumstances for any loss, damage, liability, injury or expense directly or indirectly resulting from, arising or related to the use or application of product; shall not be liable for consequential or incidental damages or loss of profits; and its liability shall be limited to replacement of the product. ALWAYS CONSULT MSDS for further details on precautions for safe handling and use.