



FLUSH WELL™ COOLING SYSTEM FLUSH



Over time cooling systems develop a build up of scale, rust and corrosion byproducts. Left untreated this build up can affect the performance of the cooling system and restrict coolant flow, resulting in overheating and cooling system failure. FLUSH WELL™ safely restores cooling system performance by flushing away these contaminants.

800-890-7935

www.wellworthproducts.com

Directions:

With engine off and cool, remove radiator cap. DO NOT REMOVE CAP WHEN ENGINE IS HOT. Drain cooling system. Close drain and refill system with clean water. Pour contents of Flush Well™ into cold radiator. Replace radiator cap and start engine. Turn heater control to maximum setting. After engine has reached operating temperature, continue to run engine for 15-30 minutes. Turn off engine. Allow cooling system and radiator to cool. Drain system and flush with clean water until water drain from system is clear. Refill with proper coolant mixture and Well Worth Kool Well™ Coolant Conditioner.

Product Number and Packaging:

#8007 – 12 oz 24/CS



PRECAUTIONS: Wash face, hands and any exposed skin thoroughly after handling. Wear eye protection/ face protection.

FIRST AID: IF IN EYES: Rinse cautiously with water for 15 minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/ attention.

PROTECTIONS: Rubber or vinyl gloves and goggles are recommended.