



# KLEEN VENT+ A/C EVAPORATOR CLEANER



KLEEN VENT + A/C Evaporator Cleaner works fast to remove foul odors in your vehicle's ventilation system. Spray directly into your evaporator drain line and the foaming action expands to encase the evaporator coil. The expanded foam sanitizes and deodorizes your evaporator and helps protect against future growth of mold, mildew and fungus.

### Directions:

Make sure the vehicle's A/C system is turned off before beginning procedure. Shake can well. Insert nozzle (or VT008 adapter and hose) into A/C evaporator drain. Spray approximately half of can contents into the drain hose. The foam will encase the evaporator coil and begin cleaning and sanitizing. Allow 10-15 minutes for the Kleen Vent+ foam to liquefy and drain back out of the drain hose. Repeat procedure with the remaining contents of the can. After draining for 10 minutes, start the vehicle, turn A/C system on with fan at low speed and run vehicle for an additional 10 minutes to complete the drying process. VT008 adaptor and hose sold separately.

### Product Number and Packaging:

#3025 Net Wt 19 OZ Aerosol.....12 per case

For complete product specifications, review the product SDS at [wellworthproducts.com](http://wellworthproducts.com).

### Storage:

Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F. Store in a well-ventilated place. Dispose of contents and container in accordance with local, regional, national and international regulations.

### First Aid:

Inhalation: Remove source of exposure or move person to fresh air and keep comfortable for breathing. If breathing is difficult, trained personnel should administer emergency oxygen if advised to do so by the POISON CENTER/doctor. If breathing has stopped, trained personnel should begin rescue breathing or, if the heart has stopped, immediately start cardiopulmonary resuscitation (CPR) or automated external defibrillation (AED). If you feel unwell/If concerned: Get medical advice/attention. Eye Contact: Rinse eyes cautiously with lukewarm, gently flowing water for 15 minutes, while holding the eyelids open. Remove contact lenses, if present and easy to do. Take care not to rinse contaminated water into the unaffected eye or onto the face. If eye irritation persists: Get medical advice/attention. Skin Contact: Wipe off with a towel. Wash with soap and water. Get medical attention if irritation persists. Ingestion: Ingestion is not a likely route of exposure. Get medical attention if you feel unwell.

Chemtrec (USA) 800-424-9300

800-890-7935

[www.wellworthproducts.com](http://www.wellworthproducts.com)