



BEAD IT!™

BLACK RTV SILICONE GASKET MAKER



Here is the fast, easy way to dispense RTV silicone. With the touch of a finger you can draw any shape or size gasket. Unique dispenser keeps product fresh longer and is more economical to use than the cartridge or tube. BEAD-IT!™ skins in about 15 minutes and is completely cured in 24 hours. Product will not shrink or crack when used as directed. Not to be used in direct contact with gasoline, fuel oil, caustic or acid solutions.

Applications: oil pans, thermostat housings, water pumps, valve covers, oil pumps, timing gears, transmission pans, axle covers.

800-890-7935

www.wellworthproducts.com

Directions:

IMPORTANT: NOT TO BE USED FOR CARBURETOR BASE, INTAKE/EXHAUST MANIFOLD OR HEAD GASKETS.

1. Use a non-flammable cleaner such as Well Worth's® BRAKE AWAY™ Brake Cleaner to remove all oil and grease. Make certain surface is clean and dry.
2. Hold nozzle at a 45° angle and with even pressure draw a bead (1/16" to 1/8" wide in any direction.
3. Using a clean dry cloth or knife, wipe away any excess RTV silicone.
4. Wait 5 minutes for bead to skin before re-assembling parts. Make sure parts are properly aligned first time. Don't over tighten bolts.

IMPORTANT: To self-close can, always allow 1/2" of BEAD IT!™ to extend past stem opening. On next use, pull upward to remove cured plug from stem.

Product Number and Packaging:
#6001 – 12 per case

For more information, see the Well Worth® Safety Data Sheet for this product.
ChemTrec (USA) 800-424-9300

CONTAINS: Triacetoxymethylsilane (17689-77-9) Methylsilanetriyl Triacetate (4253-34-3) 1,1 Difluoroethane (75-37-6), Silicon Dioxide (7631-86-9), Dimethyl Siloxane Hydroxy-Terminated (70131-67-8), Hydrotreated Petroleum Distillate (64742-46-7)



WARNING: CONTAINS GAS UNDER PRESSURE. MAY EXPLODE IF HEATED. CAUSES SERIOUS EYE AND SKIN IRRITATION.

Prevention: Wear protective gloves. Wear eye or face protection. Wash hands thoroughly after handling.

Response: IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing. Wash contaminated clothing before reuse. If skin irritation occurs: Get medical attention.
IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

Storage: Protect from sunlight. Store in well-ventilated place.

Disposal: Dispose of contents and container in accordance with all local, regional, national and international regulations.

KEEP OUT OF REACH OF CHILDREN