

VERSA LUBE™ SILICONE BASED GREASE



800-890-7935

APPLICATIONS

- BRAKE LUBRICANT (see below)
- Silicone Dielectric Compound
- Lubricates and Seals Cable Connections, Battery Terminals, Rubber Door Seals, Rubber and Plastic O-Rings, Control and Pressure Plug Valves
- · Waterproofs Electrical Connections.
- Provides a Moisture-Proof Seal for Automotive, Aircraft and Marine Ignition Systems and Sparkplug Connections.
- Use as a lubricant for assembling various metal-on-rubber and metal-on-plastic combinations.

Directions:

- Make certain surface is clean and dry before applying VERSA LUBE™. If necessary, thoroughly clean area with one of Well Worth's® shop solvents or brake cleaners.
- Spread an even coat of VERSA LUBE™ on surface to lubricate or seal. Wipe off excess

TO USE AS A BRAKE LUBRICANT: Preferred by OEM's to lubricate and quiet squeals on both Disc Brakes and Drum Brakes.

FOR USE ON DISC BRAKES: Follow step 1 and 2 above. Apply on caliper slides/sleeves, pad caliper, contact points, rubber bushings, pins & O-rings, metal side of brake parts.

FOR USE ON DRUM BRAKES: Follow steps 1 and 2 above. Apply on Anchor Pins, Self Adjuster, Shoe Contact Points, Backing Plate (Wheel Cylinder)

Product Number and Packaging: #6007 – 12 per case

www.wellworthproducts.com

CONTAINS: Siloxanes and Silicones, di-Me (CAS 63148-62-9) Silica, amorphous, fumed, cryst.-free (CAS 112945-52-5), 1,1 Difluoroethane (CAS 75-37-6)

Read Well Worth SDS before use. ChemTrec (USA) 800-424-9300



Warning: Contains gas under pressure; may explode if heated. Causes serious eye irritation. Causes skin irritation. May cause respiratory irritation.

Prevention: Wear protective gloves. Wear eye or face protection. Use only outdoors or in a well-ventilated area. Avoid release to the environment. Avoid breathing vapor. Wash hands thoroughly after handling.

Response: IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or physician if you feel unwell. IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing. Wash contaminated clothing before reuse. If skin irritation occurs: Get medical attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists, Get medical attention.

Storage: Store locked up. Protect from sunlight. Store in a well-ventilated place. Disposal Dispose of contents and container in accordance with all local, regional, national, and international regulations.

KEEP OUT OF REACH OF CHILDREN