



BEAD IT!™

HIGH TEMP RED RTV SILICONE GASKET MAKER



Here is the fast, easy way to dispense RTV silicone. With the touch of a finger you can draw any shape or size gasket. Unique dispenser keeps product fresh longer and is more economical to use than the cartridge or tube. BEAD IT!™ skins in about 15 minutes and is completely cured in 24 hours. Product will not shrink or crack when used as directed. BEAD IT!™ HIGH TEMP RED has been specifically formulated for parts that come in contact with higher temperatures. Guaranteed to perform from -85°F to over 600°F (however exposure to the top end temperatures should not be a regular continuous duration). Not to be used in direct contact with gasoline, fuel oil, caustic or acid solutions.

APPLICATIONS: HIGH TEMPERATURE CAM AND TIMING CHAIN COVERS, EXHAUST MAINFOLDS, CROSS OVER MANIFOLDS. MAY ALSO BE USED FOR ALL NORMAL SEALING AND GASKETING APPLICATIONS.

800-890-7935

www.wellworthproducts.com

Directions:

IMPORTANT: NOT TO BE USED FOR HEAD GASKET.

1. Use a non-flammable cleaner such as Well Worth's® BRAKE AWAY™ Brake Cleaner to remove all oil and grease. Make certain surface is clean and dry.
2. Hold nozzle at a 45° angle and with even pressure draw a bead (1/16" to 1/8" wide) in any direction.
3. Using a clean dry cloth or knife, wipe away any excess RTV silicone.
4. Wait 15 minutes for bead to skin before re-assembling parts. Make sure parts are properly aligned the first time. Don't over tighten bolts.

IMPORTANT: TO SELF-CLOSE CAN, ALWAYS ALLOW ½" OF BEAD IT!™ TO EXTEND PAST STEM OPENING. ON NEXT USE, PULL UPWARD TO REMOVE CURED PLUG FROM STEM.

Product Number and Packaging:

#6004 – 8 oz 12/CS

CONTAINS: Triacetoxethylsilane (17689-77-9), Methylsilyanetryl Triacetate (4253-34-3), 1,1 Difluoroethane (75-37-6), Silicon Dioxide (7631-86-9), Dimethyl Siloxane Hydroxy-Terminated (70131-67-8), Hydrotreated Petroleum Distillate (64742-46-7)



WARNING: CONTAINS GAS UNDER PRESSURE: MAY EXPLODE IF HEATED. CAUSES SERIOUS EYE AND SKIN IRRITATION.

PREVENTION: Wear protective gloves. Wear eye or face protection. Wash hands thoroughly after handling.

RESPONSE: IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing. Wash contaminated clothing before reuse. If skin irritation occurs: Get medical attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

STORAGE: Protect from sunlight. Store in a well-ventilated place.

DISPOSAL: Dispose of contents and container in accordance with all local, regional, national and international regulations.

Read SDS before using.

Chemtrec (USA) 800-424-9300

KEEP OUT OF REACH OF CHILDREN