



BEAD IT!™ CLEAR

RTV SILICONE ADHESIVE SEALANT



Here is the fast, easy way to dispense RTV silicone adhesive sealant. With the touch of a finger you can seal, fix or insulate glass, fiberglass, rubber, vinyl, wood, concrete, leather or metal. Numerous uses around the auto, boat, home, factory or farm. Unique dispenser keeps product fresh longer and is more economical to use than the cartridge or tube. BEAD-IT™ skins in about 15 minutes and is completely cured in 24 hours. Product will not shrink or crack when used as directed. Not to be used in direct contact with gasoline, fuel oil, caustic or acid solutions. Not to be used below waterline on outdoor marine applications. CANNOT BE PAINTED OVER.

APPLICATIONS: Seal, fix or insulate electrical wiring, windshields, plumbing leaks, floor tiles, windows, gaskets, etc.

800-890-7935

www.wellworthproducts.com

Directions:

1. Use a non-flammable cleaner such as Well Worth's® BRAKE AWAY™ Brake Cleaner to remove all oil and grease. Make certain surface is clean and dry,
2. Hold nozzle at a 45° angle and with even pressure draw a bead (1/16" to 1/8" wide) in any direction.
3. Using a clean dry cloth or knife, wipe away excess RTV Silicone.
4. Wait 15 minutes for bead to skin before reassembling parts. Make sure parts are properly aligned the first time. Don't over tighten bolts.

IMPORTANT: TO SELF-CLOSE CAN, ALWAYS ALLOW ½" OF BEAD IT!™ TO EXTEND PAST STEM OPENING. ON NEXT USE, PULL UPWARD TO REMOVE CURED PLUG FROM STEM.

Product Number and Packaging: #6002 – 8 oz 12/CS

CONTAINS: Triacetoxymethylsilane (17689-77-9), Methylsilanetriyl Triacetate (4253-34-3) 1,1 Difluoroethane (75-37-6), Silicon Dioxide (7631-86-9), Dimethyl Siloxane Hydroxy-Terminated (70131-67-8), Hydrotreated Petroleum Distillate (64742-46-7).

Chemtrec (USA) 800-424-9300



WARNING:
CONTAINS GAS UNDER PRESSURE: MAY EXPLODE IF HEATED.
CAUSES SERIOUS EYE AND SKIN IRRITATION.

Prevention: Wear protective gloves. Wear eye or face protection. Wash hands thoroughly after handling.

Response: IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing. Wash contaminated clothing before reuse. If skin irritation occurs: Get medical attention.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

Storage: Protect from sunlight. Store in a well-ventilated place.

Disposal: Dispose of contents and container in accordance with all local, regional, national and international regulations.

Read SDS before using.

KEEP OUT OF REACH OF CHILDREN